

REVERSIBLE HANDING OPTION

This door handing can be switched *prior to installation*. An additional sill threshold cover, in the opposite handing, must be purchased from your local Windsor Windows & Doors distributor in order to complete the handing change. See the following step by step instructions to convert.

Note:

This option cannot be done on 8-0 tall doors.

To convert handing:

- 1) Remove screen and operating panel.
- 2) Move roller assemblies from one end of the panel to the other end.
- 3) Remove aluminum threshold from frame.
- 4) Remove screen track and panel track from frame.
- 5) **Important**: Remove plastic hole plugs and place on the other end of frame. If hole plugs are left in the sill, the door will not drain properly.
- 6) Cartwheel frame and panel 180°.
- 7) Replace OX threshold with XO (or vice versa).
- 8) Replace screen track and panel track.
- 9) Reinstall screen and panel.